

DISRUPTER L.E.D. SEARCHLIGHT

INSTRUCTIONS

▲WARNING BURN HAZARD

Risk of Burn or Serious Injury
Hot Surfaces (Greater than 150°F/65°C)
Do Not Leave Unattended

Lights may become extremely hot (more than 150°F/ 65°C) when left on for more than 5 minutes, and may become too hot to touch safely. Do not leave on unattended. Do not set the light face (lens) down when turned on. Do not handle the light until it has cooled.

▲WARNING CHOKING HAZARD

Small Parts. Not for Children Under 3 Years

Browning lights are not toys. They are high performance lighting tools that contain batteries and small parts. Use only under adult supervision. Failure to follow this warning could result in serious injury or death to the child.

A lithium battery is volatile. It can explode and burn, causing a fire.

Never open a battery, place it in a fire, expose it to heat above 100 degrees centigrade, expose its contents to water, put it in backwards, or mix it with other battery types. Any of these actions can result in an explosion and/ or leaking, causing personal injury or property damage. Dispose of all batteries properly in accordance with environmental regulations.

Keep all batteries out of reach of infants and children. Do not allow infants and children to play with batteries. Do not place batteries in the nose, ears or mouth. If swallowed they may become a choking hazard and/or may cause electrical and/or chemical burns in the mouth or in the digestive tract.

If any battery is swallowed, do not induce vomiting. Immediately contact your physician, a Poison Control Center at 1-800-222-1222 toll free or the National Button Battery Ingestion Hotline at 1-202-625-3333 collect.

This light is extremely bright. Do not look directly into the light or shine it in someone's eyes.

Do not hold the lens or bezel against any portion of the human body. Do not place flashlight against combustible material or any material that can be damaged by heat. Always use with adequate ventilation.

Do not use any battery with this light other than the battery provided. The battery is not removable.

Do not use any charger, charging mechanism, or charging cables other than the parts supplied with this flashlight. Do not use the charger to charge any other product.

When recharging the battery, use either the AC charger or the mini-USB charger. Do not use both chargers at the same time.

OPERATION


SWITCH PROTECTOR RING:

Rotate the Switch Protector Ring until the window in the ring is above the rubber switch button. The switch button is located on the handle in the center of the light. When the light is not in use, rotate the ring to cover the switch, so the light cannot be turned on accidentally.

SETTINGS:

There are 6 settings: High, Medium, Low, Green, Red, Fast Strobe (Flashing).

To turn the light on, push the switch until it clicks, and release the switch. The light will be on High.



To advance to each setting, push the switch halfway down (soft toggle) until you reach the desired setting. Release the switch and the light will stay on that setting. It is not necessary to fully depress the switch or make it click to advance to the next setting.

INSTANT OFF:

After the light has been on any setting for 5 seconds or more, when the switch is fully depressed the light will turn off. This feature allows the light to be turned off quickly, without toggling through several settings.

RETURN TO HIGH:


Once the light has been turned off, the next time the switch is pushed, it will return to the first setting (High).

RECHARGING THE BATTERY

BATTERY LIFE INDICATOR LIGHTS:

When the light is turned on, the Battery Life Indicator Lights will glow blue for 5 seconds.

There are 4 Battery Life Indicator Lights. The number of lights glowing indicates the battery charge level. 4 blue lights glowing = 80-100% charged; 3 = 50-80%; 2 = 30-50%; 1 = 10-30%; 1 blinking < 10%. Recharge the battery as necessary depending on the level.



CHARGING PORTS:

Unscrew the body from the head 4-5 turns to expose the charging ports in the center of the light. There are 2 ports, a mini-USB port and a pin jack. Use the pin jack (round) for the AC charger, (wall charger) ... for the AC charger (wall charger), or the mini-USB (oblong) for the car charger. Use either the AC charger or the mini-USB charger. Do not use both chargers at the same time.

AC BATTERY CHARGE INDICATOR:

When the AC Charger (wall charger) is being used, the red light on the AC charger will glow. When the battery is fully charged, the light will change to green.

USB BATTERY CHARGE INDICATOR:

When the AC Charger (wall charger) is being used, the red light on the AC charger will glow. When the battery is fully charged, the light will change to green.

CHARGING TIME:

AC Charger: 4 hours. Mini-USB Charger: 18 hours.

RECHARGING LIFE:

The battery can be charged and depleted 500 times or more. Once charging is completed, remove the cord from the flashlight, unplug the cable from the AC outlet or DC power source, and screw the body into the head until snug. Do not over-tighten.

MAINTENANCE

Keep the light and charging equipment dry. Periodically rub a light coat of petroleum jelly onto the o-ring seals to preserve their life.

Thank you for purchasing a Browning light. Questions?
Call Browning Customer Service:
800-333-3288.



BROWNING.COM

BROWNING US: Morgan, Utah 84050-9326
BROWNING CANADA: Browning Canada Sports Ltd./Ltée,
St-Laurent, Quebec H4S 1W6
BROWNING INTL: Parc Industriel des Hauts-Sarts,
B-4040 Herstal, Belgium

MADE IN CHINA/FABRIQUÉE EN CHINE
Designed in USA/Conçue aux États-Unis